WILLOW CREEK GUITARS

www.willowcreekguitars.com

FXT USER INSTRUCTIONS

The FXT integrated effects system with chromatic tuner make Willow Creek the only acoustic guitars with this built-in feature set. You have complete and independent control of delay, chorus and reverb that play in the guitar without an amp. These effects also pass through to an amplifier. There is a condenser mic with a mix level control and a chromatic tuner. The battery is a rechargeable lithium ion and a charger is included.

FXT Instructions

To turn the system on, press and hold the "Chorus Effect" knob for about three seconds. The green LED will light. Experiment with the delay, chorus and reverb controls to experience the variety of sounds the system will produce. The bottom row of controls operate when the guitar is plugged into an amplifier. The volume control is global volume. The Mic control changes the level of the internal condenser microphone. The Tone control is a single EQ control. When the battery starts getting low, the red light will start flashing. To access the chromatic tuner simply press the Tuner button for ON and press again for Off.

